



IMPORTANT SAFETY PRECAUTIONS

Before you begin, read these instructions completely and carefully.

- Be certain electrical power is OFF before and during installation, maintenance and removal.
- Luminaire wiring must be properly grounded in accordance with the NEC and any applicable local code requirements.
- Use only UL or IEC approved wire for input/output connections.
- Verify that supply voltage matches voltage on luminaire label. Installation to any other connection may void the warranty.
- Wear gloves during installation to prevent injury and do not expose wiring to metal or sharp edges.
- Do not install in areas subject to combustible vapors or gases. Verify luminaire location ratings are suitable for installation environment (refer to specification sheet as needed).
- Do not restrict luminaire's ventilation by covering with material that will cause luminaire to overheat and potentially shorten the life span.
- Ensure LED luminaire has the correct polarity before installation.




WARNING: To reduce the risk of personal injury or property damage from fire, electrical shock, falling parts, abrasions, burns and all other hazards, read all provided warnings and follow installation instructions.

This product should be installed, inspected and maintained by a qualified and licensed electrician. Installation of luminaire must be in accordance with NEC and local code requirements.

SAVE THESE INSTRUCTIONS


INSTALLATION INSTRUCTIONS

- 1) Take out the cabinet lights from the packaging, and lay flat, with glass(B) facing up. Use the screwdriver to open the right side cover(A).
- 2) Remove the glass(B), slide cover(C) halfway off the housing. (Note: The light source plate is connected to the power cord, so please slide cover(C) gently).
- 3) Insert the power supply to the corresponding wiring terminals, then secure the front cover and the glass.
- 4) Finally, use the screw to secure the right side cover.



SEAMLESS CONNECTION AND THE KNOCK OUT LINKING

- 1) Remove plug (D) on the side cover. Insert connection plug (E) into the cabinet light.
- 2) Punch the desired knockout. Insert line pressing ring into the knockout, place the nut on the line pressing ring, and insert the conduit (F) into the line pressing ring and reload the M4 screw.



4 HOLES WIRE TERMINAL

- 1) After threading the wire through the knockout, insert the corresponding wire into the designated hole.
- 2) Wire terminal with 4 holes. The color of the wires are: black, white and green.

SAVE THESE INSTRUCTIONS